

# ABLOY<sup>®</sup> 110x36KSS-F-CE SYMMETRICAL HINGE FOR NON-REBATED EXTERIOR DOORS

#### Height adjustment ±3 mm, side adjustment +3 mm

#### Lifting the door

- · Loosen the upper adjustment screws on all hinges (1) a couple of turns.
- Tighten the lower adjustment screw (2) as much as needed (one turn raises the door by 1.25 mm).
- Tighten the lower adjustment screws (2) in other hinges so that they all support the door.
  Finish the adjustment by turning the upper adjustment screws (1) in.
- Tools needed: hexagonal key AV5

## Side adjustment

Increasing the door clearance on the hinge side

- First loosen the fixing screws and the burglary protection screw (3) on the two lowest hinges a couple of turns.
- Adjust then the hinges by turning the adjustment screws (4) clockwise as many turns as needed. (One turn moves the door approx. 2 mm towards the lock side).
- Tighten the fixing screws and the burglary protection screw (3).
- · If needed, repeat the adjustment actions on the highest hinge.
- Tools needed: hexagonal key AV4 and TORX T20

## Technical data

Screw size	5,0x25/5,0x40
SFS-EN 1935	Grade 12 (Door weight 100 kg)
Weight	0,413 kg
Packaging	Frame part 50 pcs Door part 200 pcs

This content is protected by Intellectual Property Rights Laws. The title to the content shall not pass to you, and instead shall remain with Abloy Oy or a third party holding the title. Abloy develops continuously the products and solutions offered. Therefore, the information contained in the document is subject to change without notice. ABLOY PROVIDES THIS CONTENT ON AN "AS IS" BASIS WITHOUT ANY WARRANTIES OF ANY KIND, EXPRESS, IMPLIED, OR STATUTORY."

